




- Cut out frame, door top rail and door bottom rail as per diagram
 Screw all parts into position with screws provided and retract top pivot
 Load door onto floor closer spindle and position under top pivot
 Lower top pivot into receiving hole
 Check position of door in relation to frame and adjust accordingly.

- frame and adjust accordingly
 6. Tighten all clamping screws and
- Inginen ain clamping screws and top centre grub screw.
 Open door to full extent and adjust closing speed and supplementary valves 8. Fit cover plate to floor spring 9. See adjusting instructions relating to each type of floor closer.







This drawing shows the actual stage of product development at the date indicated. No claims or damages in any form can be made against GEZE as a result of the interpretation of this drawing. This drawing remains the property of GEZE and is made available to third parties only for the duration of contractural obligations. All rights connected with this drawing remain in possession of GEZE. This drawing may not be copied or handed over to third parties without the express consent of GEZE.

							GEZE UK Ltd Blenheim Way
SB	Α						Fradley Park
Drawn Rev Date			Reason for change				•
Drawin	ıg No.			App'd	Scale	Date	Lichfield
TBUK/BAU/FI7			ΓDΑ	_	NTS	05.01.04	STAFFORDSHIRE
TItle	Title						WS13 8SY
TS 550 WITH DOUBLE ACTION							TEL +44 (0)1543 44 30 00
FITTINGS						FAX +44 (0)1543 44 30 01 www.geze.com	